

Race Proven Motors, Inc

Pure Performance

Thank you for purchasing a Race Proven Motors, Inc 3" exhaust system

Please read carefully prior to installation:

Parts List:

- (1) Mid Pipe (Connects to catalytic converter or test pipe)
- (1) Muffler or Muffler Delete Pipe
- (1) Axle Crossover Pipe
- (1) Turndown Tail Pipe
- (2) 3" Heavy Duty Clamps (may be pre installed on pipe)
- (1) 3" Saddle Clamp with hanger extension
- (1) Factory Rubber Hanger Insert
- (1) "L" Shaped Bracket for Rear Hanger



Race Proven Motors, Inc

Pure Performance

Instructions:

Start by unbolting the factory exhaust system from the cat back. You are now ready to install the new system. If using a stock or factory replacement cat your mid pipe will be necked down to the factory 2.5" cat outlet. If using a high flow 3" in/out cat or test pipe you will use the straight 3" mid pipe (specified when ordering).



We recommend starting by pre assembling the muffler or muffler delete and the mid pipe. Hang the rear of the muffler/ muffler delete pipe using the factory hanger, and provided saddle clamp. Re-use factory hardware for the catalytic converter connection.



Race Proven Motors, Inc

Pure Performance



Next insert the axle crossover pipe, and rotate into position.



Next, the turndown tailpipe section will slide over the axle pipe, and tighten with the 3" exhaust clamp. This clamp also serves as the second and final hanger. Use the provided hanger and "L" shaped bracket to support the pipe and connect to the factory hanger location. Tighten all 3 clamp assemblies and check for leaks, and overall fitment.

If you have any questions, please call 877-TURBO-11 or email Tech@RaceProvenMotors.com

Thank You,

Race Proven Motors, Inc