Pure Performance

Thank you for purchasing a Race Proven Motors, Inc 3" Typhoon exhaust system

Please read carefully prior to installation:

Parts List:

- (1) Typhoon "S" Shaped Mid Pipe (Bolts to catalytic converter or test pipe)
- (1) Muffler or Muffler Delete Pipe
- (1) Axle Crossover Pipe
- (1) Turndown Tail Pipe
- (2)3" Heavy Duty Clamps and Hanger Brackets w/ Nuts
- (1) 3" Heavy Duty Exhaust Clamp

PARTS



Pure Performance

Instructions:

Start by unbolting the factory exhaust system from the cat back, leaving the rubber hangers in place. You are now ready to install the new system. If using a stock or factory replacement cat your mid pipe will be necked down to the factory 2.5" cat outlet. If using a high flow 3" in/out cat or test pipe you will use the high flow 3" mid pipe (specified when ordering).



We recommend starting by pre assembling the muffler or muffler delete and the mid pipe. Hang the rear of the muffler/ muffler delete pipe using the provided multi purpose sealing clamp and hanger.



Re-use factory 15mm hardware for the catalytic converter connection.

Pure Performance



Next insert the axle crossover pipe, and rotate into position ensuring proper clearance for the shock, crossmember, and gas tank. * Note: Some applications will require minor trimming to the plastic gas tank cover.



Next, the turndown tailpipe section will slide over the axle pipe, and tighten with the 3" exhaust clamp. This clamp also serves as the second and final hanger. Use the provided clamp and hanger to support the pipe and connect to the factory hanger location. * Note: Loosen (2) 15mm hanger bolts and flip bracket 180 degrees so it locates further forward, then retighten.

Pure Performance





Tighten all 3 clamp assemblies and check for leaks, and overall fitment.

If you have any questions, please call 877-TURBO-11 or email Tech@RaceProvenMotors.com

Thank You, Race Proven Motors, Inc